



RHINO POWER SUPPLIES – PSP SERIES

INSTALLATION INSTRUCTIONS

PSP Series Industrial Power Supply

Part Number	* AC-Input Voltage Range	Output Power Max.	**Output	*** Output Voltage Adjustment Range	Recommended Circuit Breaker (Characteristic B)
PSP05-020S	Universal Input 85VAC - 264VAC 50 / 60Hz 85 - 375 VDC	20 Watt	5.1VDC / 4.0A	5.0 - 5.25VDC	5A
PSP12-024S		24 Watt	12.0VDC / 2.0A	12.0 - 16.0VDC	
PSP24-024S			24.0VDC / 1.0A	24.0 - 28.0VDC	
PSP24-024C		60 Watt	12.0VDC / 4.0A	12.0 - 15.0VDC	
PSP12-060S					
PSP12-060C			24.0VDC / 3.75A	24.0 - 28.0VDC	
PSP24-060S					
PSP24-060C			120 Watt	12.0VDC / 8.0A	12.0 - 15.0VDC
PSP12-120S					
PSP12-120C		24.0VDC / 5.0A		24.0 - 28.0VDC	
PSP24-120S					
PSP24-120C					

*Adjustable by potentiometer with a screwdriver.

The PSP series power supplies meet EN 61000-3-2 (PFHC: Power Factor Harmonic Current) Class A)

Input current:	@ Vin=115VAC	@ Vin=230VAC	Power Consumption	@ Vin=115VAC	@ Vin=230VAC
PSPxx-020S	0.7A typ.	0.4A typ.	PSPxx-020S	28 Watt typ.	27 Watt typ.
PSPxx-024x	0.7A typ.	0.4A typ.	PSPxx-024x	28 Watt typ.	27 Watt typ.
PSPxx-060x	1.4A typ.	0.8A typ.	PSPxx-060x	71 Watt typ.	68 Watt typ.
PSPxx-120X	2.4A typ.	1.2A typ.	PSPxx-120x	137 Watt typ.	133 Watt typ.

Output Signals

Output Voltage nominal	12.0 / 15.0 VDC	24.0 VDC
Output Voltage threshold (DC is OK)	9.0 ... 11.0V	18.0 ... 22.0V
DC OK Signal Voltage	11.0 V ± 1.0 V	22.0 V ± 2.0 V
DC OK Signal Current	60 mA	30 mA
Load Characteristic	Resistive or inductive	Resistive or inductive

General Specifications:

Operating temperature range: Natural Air Convection Cooling	-10°C - +70°C max , -14°F - +158°F max	
Output Power Derating: above +40°C [104°F]	Above +50°C Above 122°F Above +40°C Above 104°F Above +30°C Above 86°F	1.7%/K at an input voltage of 187 ... 264VAC or 265 ... 375VDC 1.7%/K at an input voltage of 187 ... 264VAC or 265 ... 375VDC 1.1%/K at an input voltage of 93 ... 132VAC or 130 ... 187VDC 1.1%/K at an input voltage of 93 ... 132VAC or 130 ... 187VDC 1.3%/K at an input voltage of 85 ... 93VAC or 85... 130VDC 1.3%/K at an input voltage of 85 ... 93VAC or 85... 130VDC
Storage temperature range:	-25°C - +85°C max (-13°F - +185°F max)	
Parallel Operation:	Up to 5 power supplies possible (standard unit)	
Connections:	Screw type plug-in connector (standard). Recommended tightening torque 0.5 to 0.7Nm (4.5 to 6.2lb.in). Spring-clamp connector (option C)	
Case material:	Grey plastic..... FR2010-110C (PC-ABS V0)	

To Install

1. Read and follow Safety and Installation instructions on the back of this page.
2. Hook top of power supply's DIN rail clip on DIN rail
3. Push down tab on top of power supply to open DIN rail clip.
4. Rotate power supply into DIN rail and release tab.
5. Verify the DIN rail clip is securely fastened on DIN rail.
6. Connect wires as indicated on power supply.



RHINO POWER SUPPLIES – PSP SERIES

Safety Instructions:

- Before installation read these instructions carefully and completely. These installation instructions cannot cover every possible installation, operation or maintenance situation. Further information can be obtained from the product datasheets, which can be downloaded, from the Internet at <http://www.automationdirect.com>.
- These power supplies are constructed in accordance with the safety requirements of IEC/EN/UL60950, EN 60204, EN50178, IEC/EN 60079-15, EN61558-2-8, UL1604 and UL508. They are approved (BG-mark) in accordance with EN60950, EN50178 and fulfil the requirements of the Low Voltage Directive (LVD). They are UL and cUL approved by CSA in accordance to UL60950 (recognised), UL508 (listed) and UL1604 (listed).
- Before any installation, maintenance or modification work ensure that the main switch is switched off and prevented from being switched on again. Non-observance, touching of any live components or improper handling of this power supply can result in death, severe personal injury or substantial property damage. Proper and safe operation is dependent on proper storage, handling, installation and operation.
- Compliance with the relevant national regulations (in the USA, Europe and other countries) must be ensured. Before operation is started the following conditions must be ensured:
 - Connection to mains supply in compliance with national regulations (NEC, NEMA, VDE0100 and EN50178).
 - Use of stranded wires, all strands must be fastened in the terminal blocks. (Potential danger of contact with the case)
 - Power supply and mains cables must be sufficiently fused.
 - Degree of protection I to IEC536. The non-fused protective earth connection must be connected to the FG terminal (Protection Class I).
 - All output wires must be rated for the power supply output current and must be connected with the correct polarity.
 - Sufficient cooling must be ensured.
- **Never work on the power supply if power is supplied!** Risk of electric arcs and electrical shock, which can cause death, severe personal injury or substantial property damage.
- **Warning:** Hazardous voltages and components storing a very substantial amount of energy are present in this power supply during normal operating conditions. However, these are inaccessible. Improper handling may result in an electric shock or serious burns! **Do not open the power supply until at least 5 minutes after it has been disconnected from the mains on all poles.**
- Only trained personnel may open the power supply.

- Do not introduce any objects into the power supply. The output voltage adjustment potentiometer may only be actuated using an insulated screwdriver.
- Keep away from fire and water

Installation Instructions:

- This power supply is designed for professional indoor systems. In operation the power supply must not be accessible. It may be installed and put into service by qualified personnel only.
- Do not operate without PE connection! To comply with EMC and safety standards (CE mark, approvals) the power supply must be operated only if PE terminal is connected to the non-fused earth conductor.
- The correct mounting position for optimal cooling performance must be observed. **Do not cover any ventilation holes.** Please allow minimum free space of 80 mm (3.15") above an elow, and 50mm (2in.) on each side of the power supply for air convection. Observe power derating.
- The internal fuse is not accessible, as it may not be replaced by the user. If this internal fuse has blown, the power supply has most properly an internal defect and, for safety reasons, must be discarded, or, if under warranty, returned. In case this internal fuse has to be replaced in the field, replace only with same type and rating of fuse for continued protection against risk of fire.
- **Recycling:** The unit contains elements that are suitable for recycling, and components that need special disposal. You are therefore requested to make sure that the power supply will be recycled environment friendly at the end of its service life.
- **Warning:** To minimize the risk of potential safety problems, follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and it is your responsibility to determine which codes should be followed and to verify that the equipment, installation, and operation are in compliance with the latest revision of these codes.
 - Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation or operations.
 - If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call us at 770-844-4200.
 - This publication is based on information that was available at the time it was printed. At Automationdirect.comTM we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without any obligation. This publication may also discuss features that may not be available in certain revisions of the product.



INSTALLATION INSTRUCTIONS

PS Series Industrial Power Supply

Part Number	AC-Input Voltage Range	Output Power max.	Output	* Output Voltage Adjustment Range	Recommended Circuit Breaker (Characteristic C)	
PS12-050D	93 – 264VAC Universal Input	50 Watt	12.0VDC / 3.5A	12.0 – 14.0VDC	5A	
PS24-050D			24.0VDC / 2.0A	24.0 – 28.0VDC		
PS12-075D	115VAC/230VAC selectable	75 Watt	12.0VDC / 6.0A	12.0 – 14.0VDC		
PS24-075D			24.0VDC / 3.0A	24.0 – 28.0VDC		
PS24-150D **	93 – 132VAC	150 Watt	24.0VDC / 6.0A	24.0 – 28.0VDC		10A
PS24-300D **	187 – 264VAC	300 Watt	24.0VDC / 12.0A	24.0 – 28.0VDC		16A
PS24-600D	50 / 60Hz	600 Watt	24.0VDC / 24.0A	24.0 – 28.0VDC	20A	
PS24-500D	115VAC 93 – 132VAC	500 Watt	24.0VDC / 20.0A	24.0 – 28.0VDC		

* Adjustable by potentiometer with a screwdriver.

** For CE compliance to EN 61000-3-2 (PFHC: Power Factor Harmonic Current) use on 115VAC or with a transformer providing isolation from the public power mains)

Operating temperature range: Natural Air Convection Cooling	-25°C - +70°C max -13°F - +158°F max	<u>Free Space Requirements:</u> Top and Bottom: 3.15 in (80 mm) Both Sides: 1.97in (50mm)
Output Power Derating:	above +50°C (122°F) → 2%/°C	Ambient air temperature measured 0.39in (10mm) below power supply
Storage temperature range:	-25°C – +85°C max -13°F – +185°F max	
Connections:	Pluggable screw type terminal COMBICON. 22-10 AWG (0.5-6.0mm ²) wire Recommended tightening torque 0.5 to 0.7Nm (4.5 to 6.2lb.in.) Use all terminals. Use a screwdriver with 0.1378 (3.5 mm) blade width (Automationdirect.com TM part DN-SS3).	
Case material:	Aluminium (chassis) and Zinc-plated steel (cover)	

Input current:	@ Vin=115VAC	@ Vin=230VAC	Power Consumption	@ Vin=115VAC	@ Vin=230VAC
➤ PSxx-050D	1.2A typ.	0.7A typ.	➤ PSxx-050D	62 Watt typ.	60 Watt typ.
➤ PSxx-075D	1.7A typ.	0.9A typ.	➤ PSxx-075D	87 Watt typ.	86 Watt typ.
➤ PS24-150D	3.0A typ.	1.7A typ.	➤ PS24-150D	168 Watt typ.	165 Watt typ.
➤ PS24-300D	5.4A typ.	3.3A typ.	➤ PS24-300D	338 Watt typ.	330 Watt typ.
➤ PS24-500D	9.5A typ.	N/A	➤ PS24-500D	545 Watt typ.	N/A
➤ PS24-600D	10.5A typ.	6.4A typ.	➤ PS24-600D	660 Watt typ.	652 Watt typ.

To Install:

1. Read and follow Safety and Installation Instructions on the back of this page.
2. Hook top of power supply's DIN rail clip on DIN rail.
3. Use Screwdriver to extend lower portion of DIN rail clip.
4. Rotate power supply into DIN rail and release lower portion of clip.
5. Verify the DIN rail clip is securely fastened on DIN rail.
6. Connect wires as indicated on power supply.

